



NOTES: FOUNDATIONS WITH REBAR

- 1 - FOOTINGS WITH REBAR IN THE FOUNDATION WILL HAVE A PIECE OF BONDED REBAR TURNED UP TO THE TOP OF THE FOUNDATION IN CLOSE PROXIMITY OF THE METER BASE.
- 2 - THE EXPOSED BONDED REBAR WILL HAVE TO CARRY THE METER BASE GROUNDING CONDUCTOR FROM THE REBAR, TO THE SUPPLEMENTAL ELECTRODE (GROUNDING ROD), AND CONTINUE TO THE METER BASE OR SERVICE EQUIPMENT DISCONNECT.
- 3 - THE GROUNDING CONDUCTOR WILL BE A MINIMUM OF #4AWG BARE COPPER IN ONE CONTINUOUS PIECE.

NOTES: FOUNDATIONS WITH OUT REBAR IN FOOTING

- 1 - FOOTINGS WITH OUT REBAR WILL CONSIST OF AT LEAST 20 FEET OF #4AWG BARE COPPER CONDUCTOR LOCATED HORIZONTALLY NEAR THE BOTTOM OF THE CONCRETE FOUNDATION OR FOOTING LEAVING ENOUGH CONDUCTOR TO GO THROUGH THE SUPPLEMENTAL ELECTRODE CLAMP (GROUNDING ROD CLAMP) AND UP TO THE METER BASE OR SERVICE EQUIPMENT DISCONNECT.
- 2 - THE GROUNDING CONDUCTOR WILL BE A MINIMUM OF #4AWG BARE COPPER IN ONE CONTINUOUS PIECE.

**GUIDE FOR METERBASE GROUNDING
COMMERCIAL AND RESIDENTIAL**

SCALE: NOT TO SCALE

DATE: 06-23-2015

DRAWN BY: BRADY T. ALLRED

SHEET NO. 1

LAWRENCEBURG UTILITY SYSTEMS

1607 N LOCUST AVENUE
LAWRENCEBURG, TN 38464
(931) 762-7161